GB

Battery Pack ZB-800-4S (item no: 16-000799)

Product description

The ZB-800-4S is a rechargeable battery pack for electrically operated chairs and sofas. It lets you place your furniture freely in the room without a cable to a wall socket, which gives a tidy look and removes the risk of tripping over a cord. The battery is charged through a Type-C input and is intended for dry indoor locations. The pack can also be used together with the furniture's power supply: if the power supply stops working, power switches to the battery without interruption. A LED shows the charging status.

Technical data

Model	ZB-800-4S
Battery type	Lithium iron phosphate ($LiFePO_4$) 18650 cells
Inner battery	12.8 V, 2000 mAh (25.6 Wh)
Output	25 V, 800 mAh (20 Wh)
Charging input	Type-C, 5 V / 9 V, 250 mA ±100 mA
Charging time	Approx. 8 hours
Nominal discharge current	1 A
Duty cycle	Max. 10%, max. 2 minutes continuous operation
Operating cycles per charge	Approx. 120 at 20 kg load, approx. 80 at 40 kg load
Charge/discharge cycles	300
Operating temperature	0-40 °C during charging and discharging
Humidity	65% ±20% RH
Storage temperature	Short term (under 1 month): -10 to 45 °C. Long term (under 6 months): 23 ±10 °C
Charge indicator	LED: red while charging, green when fully charged

Use and maintenance

Charge the battery fully before first use. This takes approximately 8 hours.

Use the battery in dry locations only, within 0-40 °C.

Check before use that the connector matches the furniture's control unit and is fitted correctly.

Operate the furniture for no more than 2 minutes at a time, and allow it to rest between operations.

If the battery hums, recharge it immediately.

After 50-60 days of storage, charge the battery fully, even if it is not used.

Charge only through the Type-C input with a 5 V or 9 V supply. Use the battery only with the provided power supply, and do not exceed its rated voltage or current.

Do not use the battery beyond 5 years.

Place the battery so there is air around it. Do not push it in between cushions or blankets.

Store in a dry, well-ventilated area.



Safety

Handle the battery with great care. Do not throw or drop it, and do not expose it to strong vibrations.

Do not put a damaged battery into operation.

Do not disassemble or alter the battery, or expose it to fire.

Do not immerse it in water.

Do not cover the battery during charging or use.

Keep away from children.

Read all instructions provided with the battery before use.



Disposal

Do not dispose of the battery with household waste.
Take it to a recycling centre
or a shop that accepts batteries.

Markings:

CE, UKCA, FCC (part 15, Class B), Canadian ICES-003, TÜV Rheinland certified

Manufacturer:

Huizhou Zhongbang Electronics Co., Ltd., Floor 1-4, No. 90 Songbai Ling Road, Sanhe Village, Tonghu Town, Zhongkai High-Tech Zone, Huizhou City, Guangdong Province, 516121, China. Made in China.